

# 2012 OSCEOLA COUNTY ANTIQUE TRACTOR PULL

Chairperson.....Mark Hall, 407-892-1055  
Co-Chairperson.....Julie Hall, 407-892-1055

1. Tractor and engine must be brand name manufactured 40 years or older in stock condition.
2. Each tractor may pull only once per weight class, per person.
3. Tractor must be running when crossing scales.
4. Driver must be seated with one hand on the steering wheel and have full control of the tractor at all times until the pull is over. DRIVER MUST WATCH FLAGMAN AT ALL TIMES.
5. The pull ends when the forward motion of the tractor stops, or the tractor goes over the side or end boundaries, or the flag is dropped. Tractor must remain in @ boundary lines, including during test pull.
6. During hook up the tractor must be in neutral with the driver's hands in the air.
7. Digging holes with tires is not allowed.
8. Any object falling off the tractor will result in the tractor being disqualified.
9. Tractors must be in safe operating condition.
10. Weights shall NOT extend beyond the front, the tractor frame, and/or sheet metal by more than two feet.
11. Consumption of ALCOHOLIC BEVERAGES before or during pull will disqualify tractor and driver.
12. Driver must sign a waiver. Drivers under 18 years of age must have a waiver signed by a parent or legal guardian. Drivers 16 years and younger must be accompanied by an adult. Adult must be in close proximity of the driver at all times and be capable of shutting down the tractor in the event the driver is endangered. Any wheel stands over 4" THE TRACTOR SHOULD BE IMMEDIATELY SHUT DOWN.
13. Tractors must have working brakes.
14. Driver must attend drivers' meeting on the day of the pull and must la-low the contents of the meeting.
15. Tractor and driver must WEIGH in before each hook.
16. Tractor and driver must be at starting gate when number is called or will forfeit the turn.
17. The Osceola County Fair Tractor Committee will address any controversy over these rules and the committee will make the final decision.
18. Reckless operation or unsafe acts on the track or pits could cause expulsion.
19. Any violation or failure to comply with these rules will result in immediate disqualification. Anything not covered by these rules will be discussed and acted upon by the officials.
20. Awards will be presented at the conclusion of pull, awards will not be shipped.
21. This page shall become a part of the rules for each class.

## V-8 CAR MOTOR

1. 3" maximum air intake on V-8's.
2. Fuel: gasoline, CAM II or aviation fuel. NO ALCOHOL.
3. 5000 RPM LIMIT.
4. Must have roll cage.
5. Driver must wear fire suit and helmet.
6. Must have strap, safety blanket, ATPA ladder bars.
7. MANDATORY WHEELIE BARS AND KILL SWITCH.
8. Weight classes: 4500 5500.
9. GENERAL RULES APPLY TO ALL CLASSES.

# 2012 OSCEOLA COUNTY ANTIQUE TRACTOR PULL

## FARM STOCK RULES 40 YEARS AND OLDER

1. Definition of a Farm Stock tractor: A stock, unaltered farm tractor pulling from a factory draw bar in low gear only, with farm type tires and wheels to the manufacturer's specifications.
2. Fuel: regular pump fuel, Cam II or aviation fuel. NO ALCOHOL.
3. Tractor must have stock wheels. Rear tires limited to farm type. NO RADIAL OR CUT TIRES.
4. Tractor must maintain stock appearance-NO ENGINE MODIFICATIONS.
5. Tractor must have factory bolt on draw bar and left in factory location. It is the puller's responsibility to furnish proof with parts book or operator's manual.
6. Tractor must maintain stock ignition system. Straight exhaust is acceptable.
7. Tractor may use factory bolt on wheel weights for make and model, or may use weight in tires.
8. Tractor moving from Farm Stock class to Super Antique MUST BE EQUIPPED WITH WHEELIE BARS AND A KILL SWITCH-THIS IS MANDATORY.
9. Hang on weights and add on wheel brackets are NOT ALLOWED.
10. Custom brackets in wheels are not allowed.
11. Tractor must use Clevis or 3" ring hitch.
12. Low gear pulling only.
13. Shifting of T.A. is not allowed.
14. Farm stock tractors may pull in any class in which they qualify.
15. Super Antique tractors are not allowed to pull in this class.
16. Removal of parts on farm stock tractors is not allowed. Examples: battery, starter, air cleaners. If the power take-off or hydraulic system pulleys are removed, they must have a steel cover in place, provided a cover was offered by the factory. The only exception to this is factory wheel weights.
17. If a part falls off while hooked to the sled, the tractor and driver are disqualified.
18. Engine high idles RPM (NO LOAD) within 10% factory specifications must have working governor, direct throttles are not allowed.
19. It is the puller's responsibility to provide proof of tractor's eligibility.
20. Classes: 3500 4500 5500 6500 7500 8500 9500 10500.
21. Tractor must be weighed in before pulling and must be at the starting gate when number is called or will forfeit the turn.
22. GENERAL RULES APPLY TO ALL CLASSES.

## SUPER ANTIQUE RULES 40 YEARS AND OLDER

1. Radial tires and dual wheels are not allowed.
2. Maximum height of draw bar is 20" to hook point, length of draw bar is 18" minimum from center of wheel to hook point.
3. Tractor must be equipped with 3" pull ring.
4. Must use factory fuels only: gasoline, CAM II or aviation fuel, no additives. NO ALCOHOL.
5. Diesels must have air intake shutoff.
6. Factory RPMs- fast idle maximum-checked with Tachometer with hand throttle full open within 30%.
7. MANDATORY WHEELIE BARS AND KILL SWITCH.
8. Weight racks allowed as follows: Front weight not to extend more than 11' from center of rear axle, Rear weights not to extend past rear tire. All weights must be secured to the weight rack. All weights must be stationary.
9. Pulling must be in first or second gear only.
10. Shifting TA's permitted.
11. It is the puller's responsibility to provide proof of tractor's eligibility.
12. Classes: 4500 5500 6500 7500 8500 9500 10500.
13. Tractor must be weighed in before pulling and must be at the starting gate when number is called or will forfeit the turn.
14. ALL GENERAL RULES APPLY TO ALL CLASSES.